Harmony™ XB4 metal 22 mm push buttons

Push buttons for manual overload reset, hour counters, buzzers, fuse carrier

Assembly of other products using body/contact assemblies, see page 48; accessories, see page 62



XB4BA8●1

Manual overload reset push buttons

Shape of head	Travel mm	Actuation distance mm	Color	Reference	Weight kg
With flush push					
	10	6 to 16	Black	**XB4BA821**	0.037
			Red	**XB4BA841**	0.037
			Blue	**XB4BA861**	0.037
		16 to 26	Black	**XB4BA822**	0.038
			Red	**XB4BA842**	0.038
			Blue	**XB4BA862**	0.038
	14	30 to 130	Black	**XB4BA921**	0.058
			Red	**XB4BA941**	0.058
			Blue	**XB4BA961**	0.058
		130 to 257	Black	**XB4BA922**	0.071
			Red	**XB4BA942**	0.071
			Blue	**XB4BA962**	0.071



ZB4BD912

Heads + mounting base for potentiometer *(1)*

Shape of head	Description	For use with	Reference	Weight kg
	For potentiometer with shaft length 45 to 50 mm	6 mm shaft	**ZB4BD912**	0.080
		6.35 mm shaft	**ZB4BD922**	0.080



XB5DS●

Hour counters

Specifications	Supply voltage V	Reference	Weight kg
Indication 0 to 9999.9	⎓ 12 to 24 - 50/60 Hz	**XB5DSB**	0.045
	∿ 120 -60 Hz	**XB5DSG**	0.045
	∿ 230 to 240 -50 Hz	**XB5DSM**	0.045



XB5KS●

Annunciators (IP 40 NEMA 1)

85 db buzzer: 4 kHz, with continuous or intermittent operation (connection diagram: see page 77)	⎓ 24 - 50/60 Hz	**XB5KSB**	0.035
	∿ 120 - 50/60 Hz	**XB5KSG**	0.035
	∿ 230 to 240 -50 Hz	**XB5KSM**	0.035



XB5DT1S

Fuse carrier

Description	For use with	Reference	Weight kg
Fuse carrier	5 x 20 mm fuse 6.3 A - 250 V	**t**	0.022

(1) Potentiometer not included.

Note: For contact block and mounting collar ordering information, see pages 48, 50, 51 and 52.