Zelio Relay - plug-in relays
RXM miniature relays

106016



RXZ E2M114M
+
Relais RXM 4AB2F7

Miniature relays without LED (sold in lots of 100)

Control circuit voltage	Number and type of contacts - Thermal current (Ith) 2 C/O - 12 A		4 C/O - 6 A	
	Unit reference	Weight	Unit reference	Weight
V		kg		kg
⎓ 12	–	–	**RXM 4AB1JDTQ**	0.036
⎓ 24	**RXM 2AB1BDTQ**	0.037	**RXM 4AB1BDTQ**	0.036
⎓ 48	–	–	**RXM 4AB1EDTQ**	0.036
⎓ 110	–	–	**RXM 4AB1FDTQ**	0.036
⎓ 220	–	–	**RXM 4AB1MDTQ**	0.036
∿ 24	**RXM 2AB1B7TQ**	0.037	**RXM 4AB1B7TQ**	0.036
∿ 48	–	–	**RXM 4AB1E7TQ**	0.036
∿ 120	**RXM 2AB1F7TQ**	0.037	**RXM 4AB1F7TQ**	0.036
∿ 230	**RXM 2AB1P7TQ**	0.037	**RXM 4AB1P7TQ**	0.036

Miniature relays with LED (sold in lots of 100)

⎓ 24	–	–	**RXM 4AB2BDTQ**	0.036
∿ 24	**RXM 2AB2B7TQ**	0.037	**RXM 4AB2B7TQ**	0.036
∿ 230	**RXM 2AB2P7TQ**	0.037	**RXM 4AB2P7TQ**	0.036

106017



RXZ E2S114M
+
Relais RXM 4AB2F7


Sockets

Contact terminal arrangement	Connection	Relay type	Sold in lots of	Unit reference	Weight kg
Mixed	Screw clamp terminals	RXM 2●●●● *(3)* RXM 4●●●●	10	**RXZ E2M114** *(1)*	0.048
	Screw connector	RXM 2●●●● *(3)* RXM 4●●●●	10	**RXZ E2M114M** *(1)*	0.056
Separate	Screw connector	RXM 2●●●●	10	**RXZ E2S108M** *(2)*	0.058
		RXM 3●●●●	10	**RXZ E2S111M** *(1)*	0.066
		RXM 4●●●●	10	**RXZ E2S114M** *(1)*	0.070

Protection modules

Description	Voltage	For use with	Sold in lots of	Unit reference	Weight kg
	V				kg
Diode	⎓ 6...250	All sockets	20	**RXM 040W**	0.003
RC circuit	∿ 24...60	All sockets	20	**RXM 041BN7**	0.010
	∿ 110...240	All sockets	20	**RXM 041FU7**	0.010
Varistor	∿/⎓ 6...24	All sockets	20	**RXM 021RB**	0.030
	∿/⎓ 24...60	All sockets	20	**RXM 021BN**	0.030
	∿/⎓ 110...240	All sockets	20	**RXM 021FP**	0.030

106018



RXM 041●●7

Timing relays

Description	For use with	Unit reference	Weight kg
2 or 4 timed C/O contacts (function A)	Sockets RXZ E●●●●●	**RE XL2●●** *(4)*	–
		RE XL4●● *(4)*	–

535195



RE XL4●●

Accessories

Description	For use with	Sold in lots of	Unit reference	Weight kg
Metal maintaining clamp	All sockets	10	**RXZ 400**	0.001
Plastic maintaining clamp	All sockets	10	**RXZ R335**	0.005
Bus jumper 2-pole (Ith: 5 A)	All sockets with separate contacts	10	**RXZ S2**	0.005
Mounting adapter for ⊔ rails *(5)*	All relays	10	**RXZ E2DA**	0.004
Mounting adapter with fixing lugs for panel	All relays	10	**RXZ E2FA**	0.002
Clip-in legends	All relays (sheet of 108 legends)	10	**RXZ L520**	0.080
	All sockets except RXZ E2M114	10	**RXZ L420**	0.001

536484



RXZ 400

(1) Thermal current Ith: 10 A
(2) Thermal current Ith: 12 A
(3) When mounting relay RXM 2●●●●● on socket RXZ E2M●●●●, the thermal current must not exceed 10 A.
(4) Please consult the "Zelio Time timing relays" catalogue.
(5) Test button becomes inaccessible.