INS40 to 160
Accessories

Connection accessories (cont.)

Connectors for bare Cu or Al cables


DB117559.eps

Snap-in	INS100 to 160 S ≤ 95 mm²	Set of 3	**28947**
		Set of 4	**28948**


DB117560.eps

Distribution connector for 3 rigid cables up to 16 mm² or 3 flexible cables up to 10 mm²	INS40 to 80	Set of 3	**19096**
		Set of 4	**19091**


DB117561.eps

Distribution connector for 4 rigid cables up to 25 mm² or 4 flexible cables up to 16 mm²	INS100 to 160	Set of 3	**28949**
		Set of 4	**28950**

Crimp lugs for copper cables


DB117562.eps

For 95 mm² cables with interphase barriers	INS100 to 160	Set of 3	**28951**
		Set of 4	**28952**

Terminal shrouds


DB117592.eps

INS40 to 80	3P/4P	Set of 2	**28955**
INS100 to 160	3P/4P	Set of 2	**28956**

Terminal shields


DB117593.eps

INS40 to 80	3P/4P	Set of 2	**28957**
INS100 to 160	3P/4P	Set of 2	**28958**

Interphase barriers


DB404166.eps

INS100 to 160	3P/4P	Set of 6	**28959**

Electrical auxiliaries

Auxiliary contacts


DB117563.eps

1 OF / CAF / CAO standard (early make or break)	INS40 to 160	**29450**
1 OF / CAF / CAO low level (early make or break)	INS40 to 160	**29452**

Rotary handles

Direct front control or lateral control			Built-in
Accessories for conversion to extended rotary handles			
Front control	Black handle	INS40 to 160	**LV428941**
	Red handle on yellow front	INS40 to 160	**LV428942**
Lateral control	Black handle	INS40 to 160	**28943**
	Red handle on yellow front	INS40 to 160 (1)	**28944**
Lateral control on PRAGMA F functional enclosure	Black handle	INS40 to 160	**28945** (2)
	Red handle on yellow front	INS40 to 160 (1)	**28946**


DB414127.eps


DB125623.eps

(1) For red/yellow switch versions only.
(2) Not available with Prisma.