Spare Parts for CP/CM Series Push Buttons


C3BK


C3CK

Code	Type	Features	Colour*	Box/Pcs
C1	Contact Block	1 NO	●	20
C2	Contact Block	1 NC	●	20
C1AU	Gold Plated Contact Block	1 NO	●	20
C2AU	Gold Plated Contact Block	1 NC	●	20
C12	Joystick Contact Block	1 NO + 1 NC	●	20
C3BK	Contact Block -	1 NO	●	20
C4BK	B Control Boxes	1 NC	●	20
C3CK	Contact Block -	1 NO	●	20
C4CK	C Control Boxes	1 NC	●	20
CPD*	Button - Plastic	Flush IP65	B K M S Y H	50
CPDS20	Selector - Plastic	Selector IP65	●	50
CPDS30	Selector - Plastic	Selector IP65	●	50
CPX*	Signal Head - Plastic		B K M S Y	50
CPDE30	Emergency Stop Head	IP65 - Turn to Release	●	50
CPDEA30	Emergency Stop Head	IP65 - Key Operated	●	50
CPDECN30	Emergency Stop Head	IP65 - Pull to Release	●	50
CPDES30	Emergency Stop Head	IP65 - With Signal	●	50
CMD*	Button - Metal	IP65	B K M S Y H	50
CMDS20	Selector - Metal	Selector IP65	●	50
CMDS30	Selector - Metal		●	50
CMX*	Signal Head - Metal		B K M S Y	50


C4BK


C4CK


CPDY


CPDS20

*Please choose the colour and replace (*) with the letter.

For Push Button / For Control Boxes


CBB


CPXK

Code		Type	Features	Colour*	Box/Pcs
CB5	/ CK5	Signal Block with LED	12-30V AC/DC	○	20
CB6	/ CK6	Signal Block with LED	12-30V AC/DC	●	20
CB7	/ CK7	Signal Block with LED	12-30V AC/DC	●	20
CB8	/ CK8	Signal Block with LED	12-30V AC/DC	●	20
CB9	/ CK9	Signal Block with LED	12-30V AC/DC	●	20
CBB	/ CKB	Signal Block with LED	100-230V AC	○	20
CBK	/ CKK	Signal Block with LED	100-230V AC	●	20
CBM	/ CKM	Signal Block with LED	100-230V AC	●	20
CBS	/ CKS	Signal Block with LED	100-230V AC	●	20
CBY	/ CKY	Signal Block with LED	100-230V AC	●	20
CBB-4	/ CKB-4	Signal Block with LED	110V AC/DC	○	20
CBK-4	/ CKK-4	Signal Block with LED	110V AC/DC	●	20
CBM-4	/ CKM-4	Signal Block with LED	110V AC/DC	●	20
CBS-4	/ CKS-4	Signal Block with LED	110V AC/DC	●	20
CBY-4	/ CKY-4	Signal Block with LED	110V AC/DC	●	20
CA		Adapter			20
CEA		Additional Adapter			10
CMB		CM Mounting Link (Metal)			20


C12


CA