Harmony™ control stations and enclosures

XAL 22 mm control stations



XALD101

Start or Stop Function
Polycarbonate; Light gray base, RAL7035; Dark gray lid, RAL7016

Description	Type of Push	Type of Contact N.O.	N.C.	Marking	Reference
Marking on Legend Holder					
1 momentary push button	Flush black	1	—	Start	**XALD101**
	Flush red	—	1	Stop	**XALD111**
Marking on Legend Holder					
1 mushroom head push button 40 mm, momentary	Red	—	1	Emergency stop on red legend	**XALD164**



XALK174

Emergency Stop or Emergency Off Function
Polycarbonate; Light gray base, RAL7035; Yellow lid, RAL1012

Description	Type	Type of Contact N.O.	N.C.	Reference
1 mushroom head push button 40 mm, red Turn-to-release	Standard *(1)*	—	1	**XALK174**
	Trigger action *(2)*	—	1	**XALK178**
1 mushroom head push button 40 mm, red Key release (Key No. 455)	Standard *(1)*	—	1	**XALK184**
	Trigger action *(2)*	—	1	**XALK188**
1 mushroom head push button 40 mm, red Push-pull	Standard *(1)*	—	1	**XALK194**

(1) Emergency Off (IEC 60364-5-53)
(2) Emergency Stop (EN / IEC 13850)



XALD211

Start-Stop Function
Polycarbonate; Light gray base, RAL7035; Dark gray lid, RAL7016

Description	Type of Push	Type of Contact N.O.	N.C.	Text	Reference
2 momentary push buttons	1 flush black	1	—	Start	**XALD211**
	1 flush red	—	1	Stop	
	1 flush black	1	—	Forward	**XALD221**
	1 flush black	1	—	Reverse	



XALD321

Three Function
Polycarbonate; Light gray base, RAL7035; Dark gray lid, RAL7016

Description	Type of Push	Type of Contact N.O.	N.C.	Text	Reference
3 momentary push buttons (no markings)	1 flush black 1 flush red 1 flush black	1	—	Open	**XALD341**
		—	1	Stop	
		1	—	Close	
		1	—	Forward	**XALD311**
		—	1	Stop	
		1	—	Reverse	
		1	—	Up	**XALD321**
		—	1	Stop	
		1	—	Down	